
Product Manual




Important: Before first use, please peel off the protective film on the watch face.

Learn how to use and set up your watch:

Scan the QR code for the video guide.

1. How to set the time?


Example: 2026-12-18(Friday) 10:58:00



Note:
Press and hold the Start/Stop(B) button to quickly increase the number when adjusting any value.


2. How to set an alarm?

Example: (Time: 12:30, Date: 14 February)




Note:
Press and hold the Start/Stop(B) button to quickly increase the number when adjusting any value.

3. How to use the stopwatch ?



Note:
The “SPL” mode to Zero, first press “D” to exit “SPL”, then press “B”, last press “D”.


4. How to use the countdown timer?



Note:
Press and hold “B” to quickly set the hour and minute.


5. How to set dual time zones?

Example: When travelling between two locations with a time difference of 5 hours 20 minutes




Note:
In standard mode, the time for another time zone is not displayed. Press “C” 3 times to switch to “DT” mode for viewing.
Press and hold the "B" button to quickly set the hour and minute.

6. How to set the hourly chime?



7. How to use the backlight?



8. How to set the 12/24-hour format?



Press "**B**" to toggle the time format.
If "**24H**" is displayed, the watch is in 24-hour format;
otherwise, it is the 12-hour format.

In standard mode

1. The watch comes with a **1-year warranty**, covering only manufacturing defects.
2. If you have any questions about the watch, please feel free to contact us, and we will actively help you resolve any issues. When contacting us, please include your order number so we can assist you more quickly.
Email: watchsupport@163.com

Thank you as:
Thank you for choosing our digital watch! Your trust is the greatest affirmation of our craftsmanship. We will continue to pursue excellence, creating precise, reliable, and thoughtfully designed products to accompany you in every precious moment.

Usage Recommendations

1. The battery type is CR2016 and can be replaced when the power runs out.
2. Do not press any buttons while swimming.
3. If there is fog or water inside the watch crystal, please contact after-sales service immediately.
4. Clean the watch case and strap with a soft cloth dampened with water; do not use alcohol, perfume, or cleaning agents.
5. Avoid severe impacts or drops to prevent damage.
6. Even if it is water-resistant, do not wear it in hot baths, saunas, or deep water.
7. Keep away from strong magnetic fields, electric fields, and high-frequency radio equipment.
8. Limit daily use of the EL backlight to no more than 5 times to extend its lifespan.
9. At temperatures between 5°C–35°C, the monthly deviation is less than ±40 seconds (meeting international standards).
10. Water resistance depth is 50 meters (5ATM), suitable for everyday water exposure but not for deep diving.
11. Carefully read the manual before first use and correctly set all functions.