




INVICTA

INVINCIBLE IN DETAIL

SINCE 1837

MANUAL & WARRANTY

The background features large, light gray, stylized letters 'C' and 'A' that are partially visible and faded. The 'C' is on the left, and the 'A' is on the right, both rendered in a modern, sans-serif font.

English

Your timepiece is backed by a comprehensive 3 year warranty, from the original date of purchase from an authorized retailer, against all manufacturing defects. All warranty claims must be accompanied by a copy of your proof of purchase. The only components covered under warranty are: the hands, dial, and watch movement. If the timepiece proves to be defective in workmanship or materials under normal use, it will be repaired free of charge at the discretion of the Invicta International Watch Service Center. Please note that a service evaluation fee will apply to all warranty service.

The manufacturer's warranty does not cover the following:

- Crystal, crown, case, strap, bracelet or battery
- Any damage that results from unauthorized or improper service, accident, impact, negligence or normal wear and tear
- Water damage due to accident, improper use, or negligence

For proper battery replacement, please contact the Invicta International Watch Service Center.

International Watch Service Center (IWSC)
9298 S 500 West,
Sandy, UT
84070
U.S.A

Please Note: We DO NOT ship to P.O. Box addresses.
A flat rate of \$28.00 will be charged to cover a service evaluation and return shipping.

The 3 Year Invicta Warranty.

Each genuine Invicta timepiece purchased from an authorized Invicta retailer is in its original and tested condition and should only be serviced through the Invicta Service Center during the warranty period in accordance with the terms of the standard 3-Year Invicta Warranty.

If Invicta timepieces are purchased from sources other than authorized retailers or are serviced or repaired by unqualified third parties, they may be subject to alterations from their original condition that are beyond the control of Invicta Watch Group.

As Invicta Watch Group cannot guarantee the quality standards of an altered timepiece, the above-mentioned standard 3-year warranty on Invicta items will be invalid. In such cases, the purchaser has to rely on the seller's warranty.

Invicta timepieces are designed, crafted and tested for superior quality with a long life expectancy. Should you discover that, despite our rigorous testing, your watch is not functioning properly during the warranty period or after, simply send it to our service center. Although our main concern lies in minimizing the time that a watch is in service, it is important for our clients to understand that every watch sent in for service is thoroughly inspected for faults in craftsmanship, material damage, movement-related irregularities, as well as other factors that could have an impact on the overall appearance and performance of the watch.

When all apparent problems are resolved, your watch will enter a two-week testing period, during which time the accuracy of the movement is observed and recorded day by day. Should your watch function properly at the conclusion of the testing period, it will be sent to you immediately. Should the technician designated to repair or overhaul your watch find it necessary to re-submit the watch into observation, your watch will be tested and observed for one more week.

Typically, the first testing phase is sufficient for most watches. However, some watches need additional attention. Should your watch be among those few, please understand that our only concern is with the performance of your watch once you receive it back. We appreciate both your understanding and patience in this case.

We offer comprehensive coverage to repair any failure or breakdown that may occur with the watch movement. We warrant that the movement will be free of defects in material and workmanship. In case of a covered defect, at our discretion, we will repair or replace your timepiece. This warranty does not cover regular wear and tear, such as scratches that may be caused by daily use on the metal band, case or crystal. The warranty will be voided if the watch has been mishandled or used under extraordinary conditions. Opening the watch by an unauthorized third party automatically voids this warranty. Under this warranty, your watch is also protected for the indicated water resistance. It is important to know that you must always keep the crowns and pushers closed and/or screwed in correctly before submerging the watch in water. Not doing so will void the warranty on the water resistance. These above stated terms and warranty apply only to new watches.

Shipping a watch for service.

The product owner will be responsible for shipping the watch to and from us. For service evaluation and return shipping, a flat rate of \$28.00 will be charged. Payment should be submitted by means of a money order, check, or credit card. Please note that we DO NOT ship to P.O. Box addresses. If your watch is not covered under the Invicta Warranty, you will be charged for the repair cost. Each repair is covered by a one year warranty, and the warranty applies to that repair only. Prices do not include sales tax.

Include:

- A copy of your purchase invoice with date.
.....
- A short description of the malfunction.
.....
- Your return address, daytime telephone, and email.
.....
- A money order or check issued to, International Watch Service Center in the amount of \$28.00 for service evaluation and return shipping.
.....
- Failure to make prior payment arrangements (money order, check, or credit card) will result in your item being returned unrepared.
.....
- **Always insure the watch with the shipper!**

Do not include:

- Gift Boxes. They will not be returned.
-

- Exotic straps. You must remove exotic straps, or we cannot accept the shipment. It will be returned to you. Please send the watch case only. The strict laws of the U.S. Government Fish and Wildlife Service prohibit the shipping of exotic species without proper documentation. Exotic species include alligator, crocodile, snake, ostrich, and fish, such as stingrays or Salmon. Please note that genuine leather straps, synthetic straps, leather embossed straps, and metal bands are EXCLUDED from this policy - you may keep those straps attached. Thank you for your cooperation.

Send your watch to:

International Watch Service Center (IWSC)
9298 S 500 West,
Sandy, UT
84070
U.S.A

Telephone: 1-800-463-6816

Email: Invicta@iwscwatchrepair.com

Important things to know.

Screw Down Crowns: Many Invicta watches are equipped with a screw down crown to help prevent water infiltration. This is most common on our Diver models. In order to adjust the date and / or time on such a watch, you must first unscrew the crown before you can gently pull it out to its first or second click stop position. To do this, simply rotate the crown counterclockwise until it springs open. When you have finished setting the watch, the crown must then be pushed in and screwed back in tightly. Not doing so will cancel the water resistance of the watch and will void all warranties from the manufacturer. Overall, this process should not require a lot of effort or force.

Tritnite® Luminous Markers: Tritnite® is an environmentally friendly luminous material used exclusively by Invicta. Tritnite® requires 4 - 5 hours of exposure to light for it to glow brightly in the dark. It will continue to perform with regular exposure to light.


Quartz, Automatic, and Manual Wind Watches.

A Quartz Watch is battery powered and does not require winding. Eventually the battery will need to be replaced.

An Automatic Watch is a mechanical watch that winds itself and does not require a battery. When worn daily, the movement of the wrist causes the mainspring to wind progressively, eliminating the need for additional winding. To start your automatic, you can hand wind it by rotating the crown clockwise a number of turns while in its normal operating position (screw down crowns will need to be unscrewed first), or by swinging it side to side for 30 seconds. We recommend housing an automatic in a watch winder box.

A Manual Wind Watch is a mechanical watch that does not require a battery, but can only be wound by hand. To wind it, turn the crown clockwise while it is in its normal operating position until you feel resistance. This type of watch should be wound daily.

Quartz, Automatic, and Manual Wind Watches.



What does this indicate?

Many Invicta watches are equipped with features that go beyond the telling of time and date. These functions are displayed on what are called subdials, indicators, counters, or zones. Your watch may have one or more of these. Knowing them will be useful when identifying which instructions pertain to your watch.

PLEASE NOTE: Because dial designs and shapes vary, not all subdials are perfectly round, or positioned in the same place.



Small Seconds:

an alternate to the sweeping center second hand, this counter makes a continuous rotation, measuring out 60-seconds.




Hours:

a chronograph function that displays elapsed hours, often in 12 one-hour intervals.



Minutes:

a chronograph function that displays minutes elapsed, often in 30 one-minute intervals (sometimes 60).



**Tenths of
a Second:**

a chronograph function that displays tenths of an elapsed second.

What does this indicate?



- **24-Hour:** often called a GMT or second time zone indicator, the hand of this counter makes a full rotation in a 24-hour period, thereby also indicating whether it is a.m. or p.m. It is often coupled with a Sun/Moon display.




- **Sun/Moon:** indicates a.m. or p.m. through the display of the sun or moon. It is often coupled with a 24-hour indicator.



- **Moonphase:** this display assures near perfect synchronization with the lunation period, and only needs adjusting every two and a half years, should the watch never stop in that time.



- **Power Reserve:** found on automatic watches, this 0 zone displays the hours of autonomy remaining of a movement after it has reached its winding peak.



Diver's Scale:

mainly found on the turning bezel of a dive watch, it allows a diver to track the time elapsed while submerged under water. It is sometimes found beneath the watch crystal and can be turned by a pusher at the 9 o'clock position.

