

Function : Hour, Minute & Second

PRESENTATION



INSTRUCTIONS MANUAL PC 21

SETTINGS

Set the Time, Hour, Minute

- 1.1 Pull the crown to position 2.
- 1.2 Turn the crown clockwise to set the hour / minute hands to the desired time.
- 1.3 Push the crown back to position 1.

